

FIG. 2




FIG. 3






FIG. 4








FIG. 6B




FIG. 7

		70A
REPRODUCTION		
	SLIDE	SHOW
	į	
		MENU
		SELECT "SLIDE SHOW" AND DEPRESS "MENU" BUTTON 70B
_		~
SLIDE SHOW		
	REPEAT	ALL 3sec FORWARD DIRECTION OFF ART
		MENU
<u> </u>		

SELECT "START" AND DEPRESS "MENU" BUTTON, THEN SLIDE SHOW IS STARTED

FIG. 8

